

# Installation Instructions



**For Model Gen2:**  
"Original"  
"Short"  
"Long"  
"Extra Short"  
"Big Block"



# Installation Instructions

## ***CAUTION:***

Under reasonable conditions, the Fridge Fixer® will keep your refrigerator doors closed while the vehicle is in motion. But, it will not prevent the refrigerator contents from shifting internally. Please load your refrigerator carefully to minimize shifting during transport, and use caution when opening as items may be poised to fall.



**Reimagine Rethink Reinvent LLC**

*Solving problems from every angle...*

# Installation Instructions

Gather needed tools:

**1**



**3/32" Hex Key**  
(Supplied with Fixer)



## #2 Phillips Screwdriver

Must have long, thin shaft to fit into door block.  
If using power screwdriver, use a long bit.




**YES**


or



**YES**



Whatever tool needed  
to remove/install  
Refrigerator Door  
Hinge Bolts  
(Varies by Manufacturer)



May also need a  
Crescent Wrench  
(or 2) if Fridge  
Fixer® Frame  
needs to be  
adjusted to fit.



**NO**

Shaft is too short and too wide



**NO**

Shaft is too short



# Installation Instructions

The Door Hinge Bolts on your refrigerator may be different than what is illustrated in these instructions. You may need to use a different tool than pictured to remove and reinstall your hardware.

To Help Identify the proper tool needed to remove and reinstall your door hinge bolts, here is a chart of common bolt head styles. You can use this name to help find the appropriate tool to use on your hardware.


 HEX FULL-BEARING	 HEX WASHER-FACED	 DOUBLE-CHAMFERED	 SQUARE	 SLOTTED-HEXAGON
 COUNTERSUNK	 RAISED-COUNTERSUNK	 ROUND	 PAN	 MUSHROOM (TRUSS)
 PHILLIPS COUNTERSUNK	 PHILLIPS RAISED COUNTERSUNK		 PHILLIPS ROUND-PAN	 PHILLIPS ROUND
 CHEESE	 RAISED-CHEESE (FILLISTER)	 "HI-TORQUE"	 COUNTERSUNK HEXAGON SOCKET	 BUTTON HEXAGON SOCKET
 FLAT OR CAP HEXAGON SOCKET	 KNURLED HEAD	 SPANNER HEAD	 TORX DRIVE	 ROBERTSON SQUARE DRIVE



# Installation Instructions

## 2

The components will be referred to by the following names:



# Installation Instructions

## **CAUTION:**

Some refrigerators will shut off the compressor if the refrigerator doors are left open for an excessive amount of time. The refrigerator may not inform you that it has entered this error state, and will simply cease to cool until it is reset.

To avoid this undesired behavior it is best to **disconnect the refrigerator from power before installing the Fridge Fixer®**. Please pull the plug, or trip the circuit breaker before proceeding.



# Installation Instructions

**3**


Remove the innermost hinge bolts from the refrigerator frame



# Installation Instructions

**4**

Use the hex key to loosen the **setscrews** on the Base (x2) and loosen the **Depth Locking Nuts** and the **Door Depth Bolts** a few turns.






# Installation Instructions




## 5

The Fridge Fixer® Frame is fabricated to accept both countersunk and flat-bottomed screw heads. If your refrigerator door hinge mounting bolts are **countersunk**, use the **countersunk side of the Fridge Fixer® Frame** (ready for use as-shipped). If your bolt heads are **Not Countersunk**, carefully remove the frame bars, turn them so the countersunk side points to the rear, and reinstall them in the Fixer. Pay particular attention to the positioning of the Frame Clamps to ensure they are oriented correctly.



# Installation Instructions

The Frame Clamp orientation is critical to proper operation of the Fridge Fixer®. If you have to reassemble the frame, ensure that the free frame bar end is inserted into the cavity that does not feed through.



# Installation Instructions

# 6

Expand the Fridge Fixer® Frame and reinstall the Door Hinge Bolts through the ends of the Frame.  
**Be sure to install the Fridge Fixer® with the “FF” Platform logo facing upwards.**

**Do not fully tighten the door hinge bolts at this time.**



# Installation Instructions

7

Slide the Frame Clamps over the free ends of the aluminum mounting frame. **Press firmly** (towards the center of the refrigerator) to secure the clamps on the free ends of the bars.



# Installation Instructions

8

Fully secure the refrigerator door hinge mounting bolts.



# Installation Instructions

The Fridge Fixer® frame will “bow” when the refrigerator door hinge bolts are tightened. This bowing is normal and helps the Fridge Fixer® to have the maximum holding force on the refrigerator doors.



# Installation Instructions

9


The Fridge Fixer® Platform needs to be centered on the refrigerator door, and centered in the gap between the refrigerator and freezer.



# Installation Instructions

**10**

If the Fridge Fixer® is not sitting level in the refrigerator door gap, or if the fixer is not centered in the door gap, use pliers or a wrench as shown to bend frame so the fixer sits level and centered.





# Installation Instructions

**1 1**

If the door hinge bolts are centered in the refrigerator door gap your Fridge Fixer® Frame should be in-line with the bolts in order to center the platform in the door gap.



# Installation Instructions

# 12

If the door hinge bolts are not centered in the refrigerator door gap your Fridge Fixer® Frame should be bent to correct for the offset, and center the platform in the door gap.



# Installation Instructions

## 13

Close refrigerator doors.


Use screwdriver to loosen Door Depth Bolts so that the back of the door block hole is fully extended beyond refrigerator doors. Loosen each side in small increments so that the front platform remains relatively parallel to the rear platform. Keep the **Depth Locking Nut** off of front platform for easier depth adjustment.

Do not extend platform so far that **end of the Depth Adjustment Bolt** is not visible past the **Rear Platform Nut**.



*Keep Front and Rear Platforms Parallel when adjusting.*

*Don't Adjust bolt with Depth Locking Nut against either Front or Rear Platform.*



*Keep Depth Adjustment Bolt visible past Rear Platform Nut.*



# Installation Instructions

# 14

Slide platform so that it is centered between refrigerator doors.



# Installation Instructions


## 15

Open refrigerator and freezer doors and tighten the **Base Set Screws** firmly (both sides) using the Hex Wrench.

### **IMPORTANT**

The design of the Platform will securely hold the aluminum bars in place with only a firm pressure from the setscrews. Do not overtighten the setscrews or the platform will fracture.

If your Platform does fracture, please contact us for a replacement.



# Installation Instructions

## 16

Close refrigerator doors and insert Door Block into Frame.

Use screwdriver to tighten Door Depth Adjustment Bolts so Door Block sits gently on refrigerator door. Door Block should be easily removable yet hold doors closed. Do not allow the **Depth Locking Nut** to hit the Rear Platform for easier adjustment.

It is normal for doors to move slightly when pulled. Frame should return doors to fully closed when door is released.



# Installation Instructions

## 17

Open refrigerator doors and tighten the **Depth Locking Nuts** against the Front Platform to lock in the depth setting. Tighten the nut firmly, but do not over-tighten.

